

Checklist

- Ensure your fillers are the same depth as your door. Any door matched filled should have the same depth as the doors. If you have loaded a filler in Revit and then revised your door style later, your filler may no longer match
- Remove comments from toekicks.
- Add any options that are not available in Revit. This includes accessories and attachments like recycle centers.

Revision #1

Created 2026-05-29 13:02:28 UTC by Laura Trabucco

Updated 2026-05-29 13:05:18 UTC by Laura Trabucco